

MORGAN'S SOLUZIONE ACIDA D-19
MORGAN'S ACID SOLUTION
Detergent for preparing sanitary ware



PROPERTIES

Hydrochloric acid-based solution for preparing sanitary ware and tiled floors prior to painting. Rids the sanitary ware's pores of lime scale and soap. Improves paint adhesion on non-porous surfaces. Prepares sanitary ware for application of MORGAN'S CERAMIC EPOXY ENAMEL (MORGAN'S SMALTO EPOSSIDICO LACCA CERAMICA).

COATING SYSTEM

Thin product with water in the ratio 1: 3 by volume and brush a generous amount over the surface. Leave on for approx. 20 minutes, rinse several times and dry with a clean rag that does not shed threads. After 4 hours, you can start applying MORGAN'S CERAMIC EPOXY ENAMEL (MORGAN'S SMALTO EPOSSIDICO LACCA CERAMICA) on the sanitary ware.

WARNINGS

Do not apply when temperature of the air, substrate or product is below +5°C. Keep in tightly sealed tin, at a temperature over +5°C.

Acid-based product (low concentration); handle with care. Use protective rubber gloves. Ventilate the room during application. Before applying finishing paints, make sure surfaces to be treated are perfectly dry.

TENDER SPECIFICATION ITEM

Washing with MORGAN'S ACID SOLUTION (MORGAN'S SOLUZIONE ACIDA), a hydrochloric acid-based product, and removal of lime scale and soap leaving the substrate to be treated perfectly clean.

MAIN DATA AT 20 °C AND 70 % RELATIVE HUMIDITY

Theoretical spreading rate Per coat sq m/l 8		Thinner water		Equipment cleaning water		Roller application NO	
Appearance and finish clear		Dust dry		Specific weight kg/l 1		Brush application WATER 1.3	
Colours colourless		Touch dry after		Solids by volume		Knife application NO	
Exterior / interior use YES/YES		Through drying after =		Viscosity =		Air-assisted spraying =	
Shelf life 36 months		Overcoating interval 4 hours		Flash point =			

As conditions and feasibility of use may be influenced by external factors beyond the manufacturer's control, the Company declines all responsibility for results.

J COLORS S.p.A.

Via Settembrini, 39 - 20020 Lainate (MI) - Italy - Tel. ++ 39 02 937541 - Fax ++ 39 02 9374114

EDITION 3/ 99 2402